

PowerCube 2.0 DC Installation Guide – Australia & New Zealand

Feb 2018

Contents

- 1. System Introduction
- 2. Unpacking the products
- 3. System Installation Steps
- 4. WIFI Monitoring Setup Guide

01

System Introduction

- System Topology
- Power Box DC
- PowerCube 2.0


PowerCube System Topology

Power Box (DC – “Hybrid Inverter”):

- DC/AC bi-directional Power Conversion Equipment (PCE)
- Mainly applied and developed for the renewable energy generation system
- The interface between the grid, solar PV and the battery storage
- Designed for lithium-ion batteries


PowerCube – Battery Energy Storage:

- Lithium Iron Phosphate (LiFePO₄)
- Contain at most 4 battery packs
- Capacity: 4.8kWh – 9.6kWh
- Voltage range: 44.5V – 54V



Power Box (DC – Bess Hybrid Inverter)



Length	610mm
Width	515mm
Height	192mm
Weight	30kg



PowerCube (Battery Storage)

Advantages:

- The PowerCube and accessories are designed for **simplicity and convenience**
- Can be **completed by one person**
- **Integrated Isolator design** to reduce the cost and time required for installation
- Outdoor rating – **IP54**



PowerCube 2.0 Casing:

Length	1000mm
Width	600mm
Height	210mm
Weight	app. 20KG

Battery Pack:

Length	410mm
Width	440mm
Height	88.5mm
Weight	25kg

02

Unpacking the products


- Battery Packs
- PowerCube 2.0 Casing
- Power Box

Battery Packs




PowerCube

Component	Part Name	Quantity
A	Casing	1
B	Battery Pack Power Cable with connectors connecting between battery packs	6
C	RJ45 communication line with connectors	3
D	Connectors without Power Cable	2
E	RJ45 communication connectors	2 (1*backup)
F	Wall plug	6
G	M8 bolt	4
H	M8 Anti-Theft bolt	2



A B C D



E



G H F

Power Box DC



Aviation Plug (Female)



Aviation Plug (Male)



Solar PV connect (2 pairs)



Communication Cable & Adapter



Anderson plug & connector (Batt)



Plug & Screw Fixings







03

System Installation Steps

- Installation tools and accessories
- Single Line Diagram
- Powerbox installation
- Powercube installation
- BESS installation
- System Initialization
- System Setting

Installation Tools

No.	Tool	Model
1		Hammer Drill Recommend drill dia. 8 & 10mm
2		Screwdriver
3		Wire stripper
4		4mm Allen Wrench
5		Crimping tools
6		Multi-meter

No.	Tool	Model
7		Marker pen
8		Measuring tape
9		Level
10		ESD gloves
11		Safety goggles
12		Anti-dust respirator



Installation Accessories

Depending on the site-specific situation and local electrical compliance requirements, some if not all of the following parts will be required:

- **AC circuit breakers** – Minimum **four 32A circuit breaker** is required next to the BESS system and inside the main switchboard. Additional ones for extended distance away from switchboard/distribution board
- **AC cables ($\geq 4\text{mm}^2$)** – From powerbox to Switchboard/Distribution board & critical loads
- **DC cables ($\geq 25\text{mm}^2$)** – From powercube to powerbox (2 to 5 metres)
- **Ethernet/CAT5 cables** – To extend the **communication cable**, distance between the powercube and the powerbox. Or to extend the **Energy meter communication cables**.
- **Conduits** – 20mm



System Connection – Single Line Diagram




- Note:
1. Battery electric cable: AWG 6# (16mm²)
 2. Smart Energy Meter Cable: AWG 24# (0.25mm²)
 3. QF rated as appropriate to AS3000

TB5200SH internal wiring diagram

Installing the hybrid inverter

- 1) Choose a **proper position** for the **mounting bracket** on the wall and **mark it**
- 2) Use **Φ10 drill** template to drill holes on marked position
- 3) Fix the **expansion bolt** into the hole
- 4) Fix wall bracket on the wall
- 5) Fix screw through bracket to expansion tube, adjust the bracket position and screw in
- 6) Align with wall bracket, move **Powerbox DC inverter** **horizontal direction** to proper position
- 7) Make the hook on wall bracket insert into the hole on the Powerbox DC inverter
- 8) Slowly **lower inverter**, ensure the inverter hang on the hook of wall bracket
- 9) Check if Inverter is properly fixed on the wall



Powercube installation – PowerCube Mounting

Step 1: Remove the **enclosure cover**

Step 2: Remove the **Circuit Breaker cover**



Step 3: Use the **cardboard template** provided to do wall-mount hole “marking” and **drill holes** accordingly.

Step 4: Insert **wall plug** and drive the **M8 bolts**

Note: Place two anti-theft bolts in the middle hole

Step 5: **Hook on the PowerCube** enclosure before securing & tightening the bolts.

Pedestal (Optional):



Powercube installation – Battery packs

Once the Powercube enclosure have been secured with bolts.

Step 1: Insert the packs into the mounted casing

Step 2: Turn the baffle to **secure** the battery packs



Powercube installation – BESS connections

Connecting the packs together

Step 1: Connect a **master** pack. The master should have the **breaker Negative cable** connected to it. It should also have the label “**Master Mode**”

Step 2: Connect rest of the **negative** cables

Step 3: Connect the **positive** cables.

*Note: for better performance, connect the **breaker positive cable** to the **last battery pack**.*

Step 4: Connect the **inverter comms cable** (to Master only)



Step 5: Connect the **comms cable** between the battery packs

Step 6: Measure the **required distance from powercube to Powerbox** & prepare a positive and negative DC cable and connect to battery breaker


Breaker Negative cable

Breaker Positive cable

Inverter comms cable



System connection – Powercube Battery pack overview




Connection Points (CP)


CP 1	Cathode (-)	CP 6	Link Port 1
CP 2	Cathode (-)	CP 7	CAN
CP 3	Anode (+)	CP 8	RS485
CP 4	Anode (+)	CP 9	POWER (ON/OFF)
CP 5	Link Port 0	CP 10	Soft Starter



System connection - Battery Modules (2 Packs) Connection - Wire




System connection - Battery Modules (3 Packs) Connection - Wire




System connection - Battery Modules (4 Packs)

Connection - Wire



BESS installation – BESS connections


Position the BESS distribution box (recommend 4 pole)



BESS installation – BESS connections

Position the BESS distribution box (recommend 4 pole)


1. Prepare and run the **comms cables, AC cables** and **conduit** (if applicable) to the DB.
2. Prepare and run the **DC cables and conduit** to the inverter.




BESS installation – Hybrid inverter Connections

Connecting the inverter cables

1. Prepare the **AC Grid** and **Critical load connectors**.
2. Connect the **AC connectors** to the inverter.
3. Connect the **Anderson plug** to the **DC cables**
4. Connect the **comms cable** to **RS485** port
5. Run the **battery comms cable** via **inverter comms conduit** to DB
6. Connect the **solar PV** cables



BESS installation – BESS connections



Connecting the comms cables (cables already labelled)

Step 1: Insert the **relay board** on to the DIN rail.

Step 2: Connect **inverter comms cable** to **relay board**

Step 3: Insert the **powercube comms cable positive** to **3**, **negative** to **6**

Step 4: Run the **energy meter comms cable** to the energy meter (to be located on the main switchboard)

To Energy Meter

BESS installation – BESS connections

Step 2: Connect to the **critical load**

Actives:


- A) Wire the **Critical load AC breaker**
- B) Wire to the **critical load**

Neutrals:

- A) Wire straight to **critical load**

Earth:

- A) Wire to **busbar**



Connecting the AC cables

Step 1: Connect to the **grid**:

Actives:

- A) Wire the **Grid AC breaker**
- B) Wire to the **Energy Meter**

Neutrals:

- A) Wire to the **Neutral busbar**


Earth:

- A) Wire to **busbar**
- B) Busbar to the **mains earth**

To Energy Meter


N Critical Load
L
E
N Energy Meter
L

BESS installation – Main Switchboard connections



BESS installation – Complete

Note: Sample Installation for reference



System Initialization – Changing settings

Note: Please **double check the connections (notably AC & DC)** before operation.





Power on the BESS system per the following steps:


1. Turn **ON PV array** isolators/circuit breakers (if applicable)
2. Turn **ON AC circuit breaker** between Power Box Grid port & Grid. The Power Box should start to operate now. You should be able to see the LCD display powered on.
3. Change the **inverter parameters** to the **correct settings** (next few slides)



System Initialization - System menu keys

Item	Symbol	Meaning	Illustration
①	ESC	Cancel	Move back to the upper item or close
②	▲	Up	Move back to the upper item or previous page
③	▼	Down	Move forward to next item or next page
④	OK	Enter/ Escape	Enter into or exit from the current page

Item	Definition	Description
	System operation light	Light on when hybrid inverter system is running smoothly
	Battery operation light	Light on if the communication between PV inverter and BMS is fine
	WiFi operation light	Light on when the WiFi is running
	Warning light	Light on when system warning occurs



System Initialization – Primary Settings

Item	Description			
PW	Password 1111 or 6666			
TIM	Time			
TYP	Battery type	00	Lithium-ion battery(default)	
		01	Lead battery	
BVH	Battery charging stop voltage (default 54V)			
BVL	Battery discharging stop voltage (default 46V)			
Id	Max discharging current(default 80A)			
Ic	Max charging current(default 50A)			
CER	Certification	00	G83	
		01	VDE 0126/4105	
		02	AS4777(default)	
CNY	PV connection	01	Only PV1	
		02	Only PV2	
		03	PV independent	
		04	PV parallel	
MDE	Operation mode	00	PV self of use(default)	
		01	Forced Time of Use(TOU)	00charging time 01discharging time
		02	Back up reserved	
		04	Slave mode	
ADR	Meter address(001-255)			
CT	Current transformer(01-99)(default 01)			
BMS	00	Trinabess	Communication mode: RS485	
SOC	Discharging stop capacity (default 20%)			
FED	Grid feed-in power (0-100%) (default 100%)			
RST	Restore to the default factory setting(RST1111)			


Highlighted section required to be adjusted to the correct setting for the system to start working. Other items are the default settings and is not required to be adjusted

System Setting – Changing the time for the first time

Time Setting:

Usually during the **first initialization**, the time need to be changed.

1. At the standard interface, long press the “OK” button for 3 seconds to **enter the setting menu**.
2. Input the **password “1111”**
3. Choose **parameters** by pressing “▲”, “▼” buttons. Go into “**TIM**” which refers to system time
4. Press “▲” or “▼” to change the 1st digit, press “OK” to switch to next digit, after inputting the current time, **press “OK”**





System Setting – Setting Smart Meter address

Smart Meter Address Setting:

Usually during the **first initialization**, the smart meter address need to be changed.

1. At the standard interface, long press the “OK” button for 3 seconds to **enter the setting menu**.
2. Input the **password “1111”**
3. Choose **parameters** by pressing “▲”, “▼” buttons. Go into **“ADR”** which refers to smart meter address
4. Check the **address column** is the same as that **on smart meter label**
5. Press “▲” or “▼” to change the 1st digit, press “OK” to switch to next digit, after inputting the correct address, **press “OK”**




System Setting – CT address

Smart Meter Address Setting:

Usually during the **first initialization**, the CT address need to be changed.

1. At the standard interface, long press the “OK” button for 3 seconds to **enter the setting menu**.
2. Input the **password “1111”**
3. Choose **parameters** by pressing “▲”, “▼” buttons. Go into **“CT”** which refers to CT address
4. Change to **01**. Press “▲” or “▼” to change the 1st digit, press “OK” to switch to next digit, after inputting the correct address, **press “OK”**




System Setting – Zero Export function (optional)

Smart Meter Address Setting:

The Zero export function can be utilized in some regions by changing in the “**FED**” settings.

1. At the standard interface, long press the “OK” button for 3 seconds to **enter the setting menu**.
2. Input the **password “1111”**
3. Choose **parameters** by pressing “▲”, “▼” buttons. Go into “**FED**” which refers to Grid feed-in power
4. Grid feed-in power XXXX% (5000*x%)X; **default 100**. Enter a value between 0 to 100%. 0 = zero export.
5. Press “▲” or “▼” to change the 1st digit, press “OK” to switch to next digit, after inputting the correct address, **press “OK”**



System Initialization – Start-up

Note: Please **double check the connections (notably AC & DC)** before operation.

Power on the BESS system per the following steps:

1. After changing all the setting. **Restart the system** by turning off all AC & DC circuit breakers (no particular order)
2. Turn **ON PV array** isolators/circuit breakers (if applicable)
3. Turn **ON AC circuit breaker** between Power Box Grid port & Grid. The Power Box should start to operate now.
4. Turn **ON all the battery packs** by pressing any one of the softstart button on the pack
5. Turn **ON DC circuit breaker/isolator** between PowerCube 2.0 & Power Box (Only when you see inverter LCD screen shows **“Wait”** which indicate success start-up)
6. Turn **ON some home appliances or load**. Make sure power consumption in the Power Box's phase is greater than 200W.
7. You should be able to **read the data on the screen**.



System Initialization – LCD display menu definition

Item list	Display contents	
PV1	Voltage	Current
PV2	Voltage	Current
BAT	Voltage	Current
AC	GRID voltage(on-grid)	GRID voltage(on-grid)
	EMERGENCY LOAD voltage(off-grid)	EMERGENCY LOAD current(off-grid)
TEM	Inverter Temperature	
FRE	Grid frequency	
ET1	Daily PV production	
SOC	Battery capacity	
SWC	software version No. of SolDate5200TLcommunication conversion board	
SWM	CPU software version No. of SolDate5200TL Master	
SWS	CPU software version No. of SolDate5200TL Slave	
SWB	CPU software version No. of BM024	

04

WIFI Monitoring Setup Guide


- Establish WLAN (Wi-Fi) Connection
- APP Setup
- BESS System Monitoring

Establish WLAN (Wi-Fi) Connection - Connecting to inverter Wi-Fi

Get **Connected with the Inverter Wi-Fi SSID** which is same as **inverter serial number**



- Open up an **internet browser** using a computer PC or from any smart device.
- Enter the **inverter IP address** in the address bar (URL) to open up its settings and configurations: **11.11.11.1**.
- Default **username: admin Password: admin**




Establish WLAN (Wi-Fi) Connection - Set-up the WLAN connection

Enter and connect to **local WiFi network SSID** and password

OR go to **“Find AP”** to choose one of the SSID from the list. Enter the **password** into the “Key” table.


- Click **“Save & Reboot”** and restart, wait at least 2 minutes. If the device IP address is **no longer 0.0.0.0**, then the device is connected to the Internet successfully.



Establish WLAN (Wi-Fi) Connection

- Set-up the user account

Visit the website portal (<http://cloud.trinabess.com>) and click “register”



The screenshot shows the 'User Register' form on the Trinabess website. At the top, there are two tabs: 'Dealer/Installer' and 'End User', with 'End User' selected. Below the tabs are several input fields: 'Username', 'Email Address', 'Hybrid' (a dropdown menu), 'Device Serial Number', 'Please select your time zone.' (a dropdown menu), 'Location', 'Password', and 'Confirm Password'. At the bottom left, there is a checkbox labeled 'Read and Accept' followed by a link to 'TrinaBESS Terms and Conditions'. At the bottom, there are two buttons: a blue 'Register' button and a grey 'Login' button.

- *Username: free to create (with 5-15 letters /figures).
- **Caution: when Username is created, it cannot be changed.**
- * Email Address: fill in a frequently-used email address. (in case of forgetting the actual password).
- * Hybrid: the type of your device, it can be selected Hybrid only.
- * Device Serial Number: EMS serial number (on the right side of your inverter).
- * Location: choose the address of your device on the map.
- * Password: 5-15 letters/figures etc.
- * Confirm Password.

APP setup

- Downloading the APP

Search “Trinabess” in app store (IOS)



For android, download via this link or QR code:

<http://cloud.trinabess.com/TrinabestAgent/resources/app/trinabess.apk>



BESS System monitoring - Demo account

Webpage: <http://cloud.trinabess.com/>

Username: pan1

Password: 123456





Thank You